

105U-3-5W wireless extension I/O installation guide



CAUTION

For continued protection against risk of fire, replace the module fuse only with the same type and rating.


Statutory requirements

EC: Unlicensed operation limits the radio power. High gain aerials may only be used to compensate for cable losses.

Antenna installation

Use Figure 1 as a guide for installing an antenna and attaching it to the module.

Figure 1. Antenna Installation



Installation

Choose a power supply option:

- 12–24 Vac, 2.0A CSA certified Class 2
- 15–30 Vdc, 2.0A CSA certified Class 2
- 11–15 Vdc or supply battery
- Solar panel with solar battery

After choosing a power supply option, wire the module as shown in Figure 2.

Note: All I/O must be SELV.


When the wiring is completed, connect the module to a computer (PC) and configure it using the configuration software. For details, refer to the user manual.

Before operating the module, read the sections on operation and configuration in the user manual to take advantage of all product features.

WARNING EXPLOSION HAZARD

Do not disconnect while circuit is live unless area is known to be non-hazardous.

Figure 2. Wiring Diagram



ELPRO Technologies
29 Lathe St
Virginia, QLD 4014
Australia
www.elprotech.com

ELPRO Technologies Inc
2028 East Ben White Blvd,
#240-5656 Austin, TX 78741-
6931
USA

Telephone:
Global:+61 7 3352 8600

Telephone:
USA: +1 855 443 5776

ELPRO is a registered trademark.
All other trademarks are property of their respective owners.

© 2021 ELPRO
All Rights Reserved

